



OPERATING & SAFETY GUIDE

PATIO HEATER

LPG

Product Code
16090

GENERAL SAFETY

Contact Event Furniture Limited for information and advice on the suitability and safety of this type of equipment.

There is a risk of injury if you do not follow the instructions printed in this guide.

This equipment should only be used by a competent adult who has read and understood these instructions.

Anyone with a temporary or permanent disability should seek expert advice before using the equipment.

Keep all children, animals and bystanders away from the work area. Ensure the floor of the work area is free from trip hazards and non-slip.

Never use the equipment if you are ill, tired or under the influence of alcohol or drugs.

Check the equipment before use, if it shows signs of damage request a replacement.

Never use the heater indoors or in a poorly ventilated space.

Never carry or pull the heater or gas cylinder by the supply hose.

Wear suitable clothing and footwear, tie back long hair. Never set up the heater near surfaces that might be damaged by heat.

Do not attempt to move the heater while it is lit. Always turn off the gas at the cylinder, then at the heater control and allow it to cool.

Always turn off the heater when not in use. Never leave the heater turned on while unattended.

It is the hirer's responsibility to ensure all necessary precautions are taken to safeguard against the risk of fire and injury.

HEALTH & SAFETY REGULATIONS

The use and storage of LPG cylinders is governed by specific regulations/legislation. Make sure you know and understand the regulations that apply and follow them. If in any doubt, contact an Event Furniture representative for advice.

GAS SAFETY

Propane is highly inflammable and heavier than air, this increases the risk of explosion.

Keep gas cylinders upright at all times, do not drop or knock them. Damaged cylinders can be dangerous.

Store gas cylinders in a secure, cool area; away from heat, possible ignition source and clear of drains or depressions where any leaked gas may collect.

Do not smoke or permit naked flames in the area when changing gas cylinders.

Handle gas cylinders and connectors with care. Carefully check the connections for leaks (use washing up liquid and look for bubbles).

NEVER test for leaks with a naked flame.

GAS LEAKS

If a gas leak is suspected...Inform everyone in the area, asking them to extinguish or turn off everything that may ignite the gas.

DO NOT OPERATE ELECTRICAL SWITCHES, THEY MAY GENERATE SPARKS.

Open any doors or windows, close cylinder valves and take cylinders into the open.

If a large amount of gas has escaped, evacuate the area and call the Fire Brigade.

OPERATING GUIDE

Position the heater with care, on a firm, level surface. The heater must be absolutely upright to reduce any risk of it falling over.

There must be a minimum clearance of 1 metre around the heater to minimise the risk of heat damage.

Open the carry case, remove the heater body, the 3 legs and the hose & regulator.

Lay the heater body on its side and fit the 3 legs to the base, ensuring they are located correctly and secured by the spring pins.

Stand the heater upright and place the deflector onto the stud located centrally on the burner top. Fold down the sliding lever on the stud to secure the deflector.

Ensure the gas hose is connected to the heater body, a simple push fit.

You can now fit the regulator to the cylinder. Make sure the black tap on the regulator is in the "off" position (down) and fit the regulator by firmly pressing down onto the cylinder's valve until you feel it lock into place.

Check for leaks (see GAS SAFETY)

Place the gas cylinder centrally beneath the heater and attach the chain hook to the cylinders handle. Raise the cylinder by pivoting the chain lever down and lock in place by attaching the small hook on the lever to the chain hook.

Attach the base cover to the legs in order to hide the cylinder from view.

To light the heater, turn on the gas at the cylinder by turning the black tap on the regulator "up". Now hold a lighted taper to the burner pilot then press and turn the control knob anticlockwise until it stops.

Once the pilot lights, keep the control knob depressed for 20 seconds to allow the safety cut out to activate. This will close down the gas supply if the flame is extinguished.

The control knob can now be used to adjust the heat.

If the heater fails to light, turn the gas supply off and wait for any un-burned gas to clear before repeating the lighting procedure.

To finish...Close the gas cylinder valve, when the burner has gone out, you can then turn the gas control tap on the heater fully clockwise.

Leave the heater to cool before disconnecting the gas regulator by pressing in the black tap and at the same time pulling the regulator upwards .

Once cool dismantle and repack the heater by reversing the set up instructions.

ANY PROBLEMS

Contact: Event Furniture Ltd. 01922 628961

Event Furniture Limited,
Unit2, Maple Leaf Industrial Estate
Bloxwich Lane, Walsall,
West Midlands, WS2 8TF